

Special care for installation of hose assemblies (diameter above 100 mm).

2015

Incorrect



Correct



Incorrect



Correct



For transportation, installations or support in place, never use a single rope to lift hose. Only slings in sufficient numbers depending of the hose lengths.

Correct

For handling in straight length, a lifting beam must be used imperatively.

We recommend the use of slings (150 mm wide minimum).

Number of slings should be at least:

- 2 for length < 6 m
- 3 for length of 6 to 8 m
- 4 for length > 8 m

